

MODELS – JV00** AQUALAND ECO-DRIVE

Mvmt. Cal. No. U10*

FEATURES

- ☐ Water-Resistant to 200 Meters
- ☐ Light Powered
- ☐ Depth Meter
- ☐ Water Temperature Gauge
- ☐ Battery Charge Level Indicator
- ☐ Electro-Luminescence Backlighting
- ☐ 3 Alarms
- ☐ Auto Diving Mode
- ☐ 2 Time Zones
- ☐ Calendar

BENEFITS

- ☐ Environmentally Clean Energy Source
- ☐ Current and Maximum Depth
- ☐ Measures Current and Lowest Water Temp
- ☐ Quick Reference to Energy Cell Charge
- ☐ Display Visible in Low Light
- ☐ Set Each Alarm for Home or Different Time Zone

 Please view our interactive setting instructions @ www.citizenwatch.com

IMPORTANT NOTE: Before diving, be sure the watch is fully charged. The charge level can be determined by referring to the function hand and its relative position to the charge level scale.

If a low/no charge state is reached, or the function hand stays on the 'over zone' mark, or another malfunction is experienced, then the ALL RESET and 0-POSITIONING procedures will be required.

0-POSITION CHECK PROCEDURE

- ☐ Press and release the lower left button (D) until the RESET mode is shown (indicated by the word 'RESET' at the top of the digital display).

RESET
a12:00
00
DP-00

This will cause each hand to move to the 0-POSITION stored in memory. The 0-positions for the hands are: hour, minute and second hands at the 12:00 position, and the multi-function hand at the 0 position. If the hands do not move to these positions, continue with the following ALL RESET and 0-POSITIONING procedures.

ALL RESET PROCEDURE AND 0-POSITIONING PROCEDURES

- ☐ Press and hold all buttons simultaneously for 3 seconds and release. The following confirmations will occur: an audible beep will sound, the digital display will indicate "ALL RESET", the hour, minute, second and multi-function hands will move back and forth and the EL backlight and LED will flash. The display will return to the 'RESET' display shown above.
- ☐ Press and hold the upper left button (C) for two seconds. '00' will flash in the lower right portion of the display. If the multi function hand is not pointing to '0', press and release the upper right button (B) until the multi-function hand is pointing to '0'. (Note: you may press and hold the upper right button (B) to rapidly advance the multi-function hand.)
- ☐ Press and release the upper left button (C). The digital hours will flash. If the hour hand is not pointing to the 12:00 position, press and release the upper right button (B) until the hour hand is pointing to the 12:00 position. (Note: you may press and hold the upper right button (B) to rapidly advance the hour hand.)
- ☐ Press and release the upper left button (C). The digital minutes will flash. If the minute hand is not pointing to the 12:00 position, press and release the upper right button (B) until the minute hand points to the 12:00 position. (Note: you may press and hold the upper right button (B) to rapidly advance the minute hand.)
- ☐ Press and release the upper left button (C). The digital seconds will flash. If the second hand is not pointing to the 12:00 position, press and release the upper right button (B) until the second hand points to the 12:00 position. (Note: you may press and hold the upper right button (B) to rapidly advance the second hand.)
- ☐ Press and release the upper left button (C). This completes the ALL RESET and 0-POSITIONING PROCEDURES. The hour, minute and second hands will operate in conjunction with the digital display. The time and calendar must be set.

TO SET THE TIME AND CALENDAR

- ☐ Press and release the lower left button (D) until the 'normal' display mode is shown in the digital display (time zone, date and day)

LAX
8/30
TUE



- ☐ Press and hold the upper left button (C) for two seconds and release. The seconds indicated on the digital display will flash, the hour, minute and second hands will move to the 12:00 position. If this does not occur, an ALL RESET and 0 POSITIONING must be performed. If the hands move to 12:00, continue with setting the time and calendar.
- ☐ Press and release the lower right button (A) to reset the digital seconds display to '00'.
- ☐ Press and release the upper left button (C). The time zone will flash.
- ☐ Press and release the upper right button (B) to advance the time zone or lower right button (A) to reverse the time zone to your location.
- ☐ Press and release the upper left button (C). 'S' (daylight savings time on) will flash.
- ☐ Press and release the upper right button (B) to activate (ON) or deactivate (OFF) daylight savings time.
- ☐ Press and release the upper left button (C). The hours will flash.
- ☐ Press and release the upper right button (B) to advance the hours or lower right button (A) to reverse the hours. Be sure to note the correct AM or PM setting.
- ☐ Press and release the upper left button (C). The minutes will flash.
- ☐ Press and release the upper right button (B) to advance the minutes or lower right button (A) to reverse the minutes.
- ☐ Press and release the upper left button (C). The month will flash.
- ☐ Press and release the upper right button (B) to advance the month or lower right button (A) to reverse the month.
- ☐ Press and release the upper left button (C). The date of month will flash.
- ☐ Press and release the upper right button (B) to advance the date of month or lower right button (A) to reverse the date of month.
- ☐ Press and release the upper left button (C). The year will flash.
- ☐ Press and release the upper right button (B) to advance the year or lower right button (A) to reverse the year.
- ☐ Press and release the upper left button (C). The 12H or 24H indicator will flash.
- ☐ Press and release the upper right button (B) to select 12-hour (12H) or 24-hour (24H) time display
- ☐ Press and release the upper left button (C) to finalize setting. The hour, minute and second hands will move to the time set in the digital display.

TO SET THE DAILY ALARM

There are three daily alarms that may be set independently of one another. Setting procedure is the same for each alarm time.

- ☐ Press and release the lower left button (D) until the 'alarm 1' display mode is shown in the digital display (alarm number, on/off, alarm time and time zone).

1 OFF
a 6:00
LAX

- ☐ Press and hold the upper left button (C) for two seconds then release. The 'ON' mark on the display will flash, the hour and minute hands will move to the 12:00 position. (If the hour and minute hands do not move to the 12:00 position, an ALL RESET and 0-POSITIONING will need to be performed before proceeding.)
- ☐ Press and release the upper right button (B) to turn the alarm ON or OFF.

- ☐ Press and release the upper left button (C). The time zone will flash.
- ☐ Press and release the upper right button (B) to advance the time zone or lower right button (A) to reverse the time zone to your location.
- ☐ Press and release the upper left button (C). The alarm hours will flash.
- ☐ Press and release the upper right button (B) to advance the hours or lower right button (A) to reverse the hours. Be sure to note the correct AM or PM setting.
- ☐ Press and release the upper left button (C). The alarm minutes will flash.
- ☐ Press and release the upper right button (B) to advance the minutes or lower right button (A) to reverse the minutes.
- ☐ Press and release the upper left button (C) to finalize setting.

TO SET THE TRAVEL TIME (SECOND TIME ZONE) A second time zone can be shown in the digital display.

- ☐ Press and release the lower left button (D) until the 'travel' display mode is shown in the digital display (TRV, time zone, time, date).

<TRV>
NYC
a 1:09
8/30

- ☐ Press and release the lower left button (D).
- ☐ Simultaneously press and hold the lower right button (A) and upper left (C) buttons. The digital display must indicate your home time zone, daylight savings time setting and time of your home location. If this does not occur, you must set the time and calendar for your home time zone.
- ☐ Press and release the upper left button (C). The time zone will flash. The hour and minute hands will move to the 12:00 position. (If the hour and minute hands do not move to the 12:00 position, an ALL RESET and 0-POSITIONING will need to be performed before proceeding.)
- ☐ Press and release the upper right button (B) to advance the time zone or lower right button (A) to reverse the time zone.
- ☐ Press and release the upper left button (C). 'S' (daylight savings time on) will flash.
- ☐ Press and release the upper right button (B) to activate (ON) or deactivate (OFF) daylight savings time.
- ☐ Press and release the upper left button (C) to finalize setting.

For further instructions and details of the many additional features of this model, please refer to the full instruction manual or our web site at www.citizenwatch.com